

Coated MDF skirtings instructions

CONSIDERATIONS TO BE TAKEN INTO ACCOUNT

- Prior to the installation of the skirtings, make sure that the walls don't show any sign of dampness. The walls should be completely dry to prevent moisture from transferring to the skirting board, therefore also check that the walls have not just been painted.
- Cut the pieces to size: To make a perfect cut, make use of a circular miter saw, this one should be in a good condition. Start cutting on the decorative side.

INSTALLATION

Two techniques can be used for fixing:

- Mechanical fixation with needles
- Fixation by using wood assemble adhesives without solvents.

Do not use contact adhesives in between the skirting joints if these contain cyanoacrylate or similar. Use the same adhesive as for the wall.

IMPORTANT: : Do not use silicones of any kind, nor adhesives that contain solvents in their composition.

- If masking tape or painter's tape is to be placed on the skirting, it must be easily removable (with little to no power of removal). Never leave it in place for a period of more than 16 hours.
- If the walls have irregularities, such as stippled-finish paintwork or non-level walls, gaps may appear in between the wall and skirting. To cover these gaps, filler must be used, never silicone or materials with solvents.